

APW-895NE(Economy type)

Lockstitch Automatic Welting Machine (for straight pockets without flaps)






SPECIFICATIONS

Model name	APW-895NE			
Sewing speed	Max. 3,000 sti/min*			
Kind of welts	Parallel double welt, parallel single welt(without flaps)			
Stitch length	Standard 2.5mm (2.0~3.4mm)			
Stitch length (fastening stitching)	Condensation stitching: Standard 1.0mm (0.5~1.5mm) Back-tack stitching: Standard 2.0mm (0.5~3.0mm) *Changeable between condensation / back tack stitching			
Corner-knife cutting adjusting method	Mechanical adjustment			
Needle	DP x 17 Standard #16 (#14~#18), 190R Standard #100 (#100~#110)			
Thread	SPUN #60 (recommend)			
Hook	Vertical-axis 1.7-fold capacity hook			
Number of independent sewing patterns	99 patterns (999 patterns when a CF memory card is used)			
Number of cycle sewing patterns	20 patterns			
Number of alternate sewing patterns	20 patterns			
Machine head	2-needle, lockstitch machine			
Cloth feeding system	Driven by a stepping motor			
Compressed air /Air consumption	0.5MPa, 40dm³/min (ANR)			
Weight	238.5kg			
Dimensions	1,095mm(W)×1,500mm(D)×1,200mm(H)			

Model name	With / Without (corner knife)		Sewing length (welt length)	Needle gauge (mm)
APW-895NE (Economy type)	Without	Min	18mm~Max. 220mm (settable in increments of 0.1mm)	
	With	Wh	. 35mm on a solenoid valve is used: Min. 21mm a needle gauge width of 14mm or more, the minimum sewing length is 50mm.	10, 12



JUKI ECO PRODUCTS

APW-895NE is an eco-friendly product which complies with JUKI ECO PRODUCTS standards for protecting the environment.



• The sewing machine complies with the "Juki Group Green Procurement Guidelines" on the use of hazardous substances, which is stricter than other restrictions, such as those of the RoHS Directive.

For details of JUKI ECO PRODUCTS, refer to : http://www.juki.co.jp/eco_e/index.html









APW-895NE (Economy type)



2-11-1, TSURUMAKI, TAMA-SHI, TOKYO 206-8551, JAPAN PHONE: (81) 42-357-2370

FAX: (81) 42-357-2274

- $\begin{tabular}{ll} * Specifications and appearance are subject to change without prior notice for improvement. \end{tabular}$ * Read the instruction manual before putting the machine into service to ensure safety.
- * This catalogue prints with environment-friendly soyink on recycle paper.

APW-895NE (Economy type)

APW-895NE provides excellent performance and high productivity in welting, such as slacks and working pants. It comes with a high-speed machine head that is able to perform sewing at 3,000 sti/min at the maximum. Even an inexperienced operator can easy sewing slacks and working pants by just placing the fabric on the welting machine and carrying out the start operation.








Adjustment of the corner knife


The corner knives, which can be drawn out in the entire knife unit is adopted.

The knives are easily adjusted and can also be changed with ease. The slim corner knife cover helps reduce material thrusting, thereby achieving material cutting with accuracy. Loosen the screw and manually adjust the position of corner knives.

■ Drawer type of entire knife unit



Manually adjust the position of corner knives





Standard equipment

Pocket bag presser device



When performing welting of slacks and working pants, the pocket bag presser device clamps the pocket bag for sewing it simultaneously with welting.

Dart stretcher



The dart stretcher clamps the end of material to smooth out the wrinkles on a garment body, thereby allowing the sewing machine to perform welting with consistency.

HOperation pedal



One-shot operation pedal is adopted to start the sewing machine. The sewing step is moved forward by depressing the front part of pedal, and it is moved backward by depressing the rear part of pedal.

Selection & Sewing position by control panel

APW-895NE is equipped with a function to select a sewing position (from the operator side, from the counter operator side, at the center of the sewing length) when changing the length of the pocket. Note that the moving marker (option) is required if you wish to automatically move the marker line.

